



Where $H+W$ is less than or equal to 500mm, the membrane must be bonded using either:

- HA ADHESIVE - Contact adhered.
- For fleece backed membranes.
- MS LASTIC ADHESIVE - Fully adhered.
- For unbacked and fleece backed membranes.
- For parapets over 800mm high, peel stops must be employed @ 800mm followed by every 300mm.

KEY:

UNBACKED EVALON

EVALON V/VSK

GENERIC SUBSTRATE

Notes:



WATERPROOFING

Description:
Fully Bonded Parapet Walls
 $H+W <+500mm$

This is a standard generic detail and should be used for reference purposes only, and not form part of a specification document.

PRODUCT: ALWITRA
EVALON V/VSK

Drawing Date: JUNE 2021

Scale: NTS

Drawing No: EVA STD -3.10A	Rev. 3	Sheet 1 / 1
-------------------------------	-----------	----------------